



Emotional Balance Board Assembly



Package

Each Emotional Balance Board set comes with two (2) Emotional Balance Boards printed on coroplast and a clear plastic hinge.



Assembly

Place the corner of the first board in the wider section on one side of the hinge. Push the sign through the hinge until the edges are flush. Repeat with the second board.



Use

Once both boards are connected to the hinge, please use on a flat surface for best results. Coroplast is weather resistant and waterproof. To enhance longevity in harsh weather conditions, consider removing the item from extended outdoor exposure.

www.lakeshorespeech.com

[Refund Policy](#)